

## Instructions how to make your own C-cassette bracelet

### Materials:

C-cassette with screws

Hinge 2,5cm,

Zipper 6cm,

(Two pieces of felt size 6cm x 10cm, optional)



1. Open C-cassette with screwdriver and remove the pieces inside (if you want your tapes inside the C-cassettes to be used as material for wallets, please send the tapes to Hemming&Willström). Remember to store the screws.
2. Smooth the edges inside the C-cassette covers.
3. Bend the covers in hot water.
4. Make holes for the hinge to the C-cassette covers.
5. Attach the hinge to the covers with instant glue.
6. Attach zipper with instant glue to the sides of C-cassette.
7. Cut the pieces of felt to the form of bended covers.
8. Glue the pieces of felt inside the covers.
9. Glue the screws back to their places.
10. Put the bracelet on and get jiggy with it!